

Ligation sequencing gDNA V14 - human sample (N50 10 kb)  
on PromethION (SQK-LSK114)

Version: GDH\_9173\_v114\_revJ\_10Nov2022  
Last update: 29/02/2024

Flow Cell Number: .....

DNA Samples: .....

### Before start checklist

#### Materials

1 µg high molecular weight genomic DNA or 5 x 10<sup>8</sup> cells (e.g. cell culture or tissue sample)

Ligation Sequencing Kit V14 (SQK-LSK114)

#### Consumables

NEBNext® Companion Module for Oxford Nanopore Technologies® Ligation Sequencing (NEB, E7180S or E7180L). Alternatively, you can use the NEBNext® products below:

NEBNext FFPE Repair Mix (NEB, M6630)

NEBNext Ultra II End repair/dA-tailing Module (NEB, E7546)

NEBNext Quick Ligation Module (NEB, E6056)

Puregene Cell Kit (QIAGEN, Cat. # 158043)

g-TUBE™ (Covaris, Cat. # 520079)

15 ml Falcon tubes

2 ml Eppendorf DNA LoBind tubes

1.5 ml Eppendorf DNA LoBind tubes

0.2 ml thin-walled PCR tubes

Nuclease-free water (e.g. ThermoFisher, AM9937)

Freshly prepared 70% ethanol in nuclease-free water

Isopropanol, 100% (Fisher, 10723124)

Phosphate Buffered Saline (PBS), pH 7.4 (Thermo Fisher, 10010023)

TE buffer (10 mM Tris-HCl, 1 mM EDTA, pH 8.0) (Fisher scientific, 10224683)

(Optional) TE buffer (10 mM Tris-HCl, 0.1 mM EDTA, pH 8.0)

Inoculation loop or disposable tweezers

Qubit™ Assay Tubes (Invitrogen, Q32856)

Qubit dsDNA BR Assay Kit (Invitrogen, Q32850)

Qubit dsDNA HS Assay Kit (Invitrogen, Q32851)

#### Equipment

Hula mixer (gentle rotator mixer)

Magnetic rack, suitable for 1.5 ml Eppendorf tubes

Incubator or water bath set at 37°C and 50°C

Centrifuge and rotor suitable for 15 ml Falcon tubes

Microfuge

Vortex mixer

Thermal cycler

Ice bucket with ice

Timer

Agilent Femto Pulse System (or equivalent for read length QC)

Qubit fluorometer (or equivalent for QC check)

Pipettes and pipette tips P2, P10, P20, P100, P200, P1000

Ligation sequencing gDNA V14 - human sample (N50 10 kb)  
on PromethION (SQK-LSK114)

Version: GDH\_9173\_v114\_revJ\_10Nov2022  
Last update: 29/02/2024

Flow Cell Number: .....

DNA Samples: .....

INSTRUCTIONS	NOTES/OBSERVATIONS
<p><b>Human cell line DNA extraction using the QIAGEN Puregene Cell Kit</b></p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Prepare a 1.5 ml Eppendorf DNA LoBind tube with approximately 1 ml of 70% ethanol and store on ice to cool.</li> <li><input type="checkbox"/> We recommend to harvest and pellet <math>5 \times 10^6</math> cells in a 1.5 ml Eppendorf DNA LoBind tube. However, this may vary depending on your sample type. If any liquid remains associated with the pellet, spin down the cells again, then aspirate and discard the remaining supernatant.</li> <li><input type="checkbox"/> Add 200 <math>\mu</math>l of 1x PBS to pelleted cells.</li> <li><input type="checkbox"/> Centrifuge at 300 x g for 3 minutes.</li> <li><input type="checkbox"/> Without disturbing the pellet, aspirate and discard the supernatant.</li> <li><input type="checkbox"/> Add 2 ml of Cell Lysis Solution to the washed cell pellet and resuspend the cells using a wide-bore pipette tip.</li> <li><input type="checkbox"/> Transfer the resuspended cells to a 15 ml Falcon. If clumps of cells remain, gently invert the tube to ensure resuspension.</li> <li><input type="checkbox"/> Incubate the sample at 37°C for 30 minutes.</li> <li><input type="checkbox"/> Add 700 <math>\mu</math>l of the Protein Precipitation Solution to the lysed cells and mix by vortexing for three pulses of 5 seconds.</li> <li><input type="checkbox"/> Centrifuge the sample at 2000 x g for 5 minutes.</li> <li><input type="checkbox"/> Transfer the supernatant to a new 15 ml falcon tube and add 2.5 ml isopropanol at RT. Discard the pellet.</li> <li><input type="checkbox"/> Mix by gently inverting the tube 50 times.</li> <li><input type="checkbox"/> Spool the DNA using an inoculation loop or disposable tweezers.</li> <li><input type="checkbox"/> Briefly dip the spooled DNA in the 1.5 ml Eppendorf DNA LoBind tube containing cold 70% ethanol and allow to air dry for a few seconds.</li> <li><input type="checkbox"/> Transfer the inoculation loop or tweezers with the spooled DNA to a 1.5 ml Eppendorf DNA LoBind tube containing 250 <math>\mu</math>l TE buffer (10 mM Tris-HCl, 1 mM EDTA, pH 8.0) and allow the DNA to gently dislodge from the loop/tweezers.</li> <li><input type="checkbox"/> Incubate the DNA pellet for 2 hours at 50°C, occasionally mixing the tube by gentle inversion to aid dissolving the pellet. Alternatively, the DNA pellet can be left overnight at RT.</li> <li><input type="checkbox"/> Quantify the sample three times using the Qubit dsDNA BR Assay Kit, ensuring that replicate Qubit measurements are consistent before continuing to the next step.</li> </ul>	
<p>Take the sample in 250 <math>\mu</math>l TE buffer forwards into the next step or the sample can be stored at 4°C overnight.</p>	
<p><b>Shearing DNA for 10 kb input using the Covaris g-TUBE™</b></p>	

Ligation sequencing gDNA V14 - human sample (N50 10 kb)  
on PromethION (SQK-LSK114)

Version: GDH\_9173\_v114\_revJ\_10Nov2022  
Last update: 29/02/2024

Flow Cell Number: .....

DNA Samples: .....

INSTRUCTIONS	NOTES/OBSERVATIONS
<p><input type="checkbox"/> Transfer 2 µg extracted gDNA into a 1.5 ml Eppendorf DNA LoBind tube, and adjust the volume to 100 µl with Nuclease-free water.</p> <p><input type="checkbox"/> Mix the DNA thoroughly by flicking the tube. Spin down briefly in a microfuge.</p> <p><input type="checkbox"/> Transfer the genomic DNA sample in 100 µl to a Covaris g-TUBE™.</p> <p><input type="checkbox"/> For a fragment length of 10 kb, centrifuge the g-TUBE™ at 4300 x g for one minute at RT. Remove and check that all the DNA has passed through the tube.</p> <p><input type="checkbox"/> Invert the g-TUBE™ and centrifuge again for one minute to collect the fragmented DNA. Remove and check that all the DNA has passed through the tube.</p> <p><input type="checkbox"/> Transfer the 100 µl fragmented DNA into a clean 1.5 ml Eppendorf DNA LoBind tube.</p>	
<p>Quantify 1 µl of eluted sample using a Qubit fluorometer and check sample read length using the Agilent Femto Pulse System. An N50 of 10 kb read lengths is to be expected.</p>	
<p>Take forwards 1 µg sample into the next step or the sample can be stored at 4°C overnight.</p>	
<p><b>DNA repair and end-prep</b></p>	
<p><input type="checkbox"/> Thaw DNA Control Sample (DCS) at RT, spin down, mix by pipetting, and place on ice.</p> <p>Prepare the NEBNext FFPE DNA Repair Mix and NEBNext Ultra II End Repair / dA-tailing Module reagents in accordance with manufacturer's instructions, and place on ice.</p> <p><input type="checkbox"/> Thaw all reagents on ice.</p> <p><input type="checkbox"/> Flick and/or invert the reagent tubes to ensure they are well mixed. Note: Do not vortex the FFPE DNA Repair Mix or Ultra II End Prep Enzyme Mix.</p> <p><input type="checkbox"/> Always spin down tubes before opening for the first time each day.</p> <p><input type="checkbox"/> The Ultra II End Prep Buffer and FFPE DNA Repair Buffer may have a little precipitate. Allow the mixture to come to RT and pipette the buffer up and down several times to break up the precipitate, followed by vortexing the tube for 30 seconds to solubilise any precipitate. Note: It is important the buffers are mixed well by vortexing.</p> <p><input type="checkbox"/> The FFPE DNA Repair Buffer may have a yellow tinge and is fine to use if yellow.</p> <p>Prepare the DNA in Nuclease-free water</p> <p><input type="checkbox"/> Transfer 1 µg of 10 kb gDNA into a 1.5 ml Eppendorf DNA LoBind tube</p> <p><input type="checkbox"/> Adjust the volume to 47 µl with Nuclease-free water</p> <p><input type="checkbox"/> Mix thoroughly by pipetting up and down, or by flicking the tube</p> <p><input type="checkbox"/> Spin down briefly in a microfuge</p> <p>In a 0.2 ml thin-walled PCR tube, mix the following:</p> <p><input type="checkbox"/> 47 µl DNA from the previous step</p> <p><input type="checkbox"/> 1 µl DNA CS (optional)</p> <p><input type="checkbox"/> 3.5 µl NEBNext FFPE DNA Repair Buffer</p> <p><input type="checkbox"/> 2 µl NEBNext FFPE DNA Repair Mix</p> <p><input type="checkbox"/> 3.5 µl Ultra II End-prep Reaction Buffer</p> <p><input type="checkbox"/> 3 µl Ultra II End-prep Enzyme Mix</p>	

Ligation sequencing gDNA V14 - human sample (N50 10 kb)  
on PromethION (SQK-LSK114)

Version: GDH\_9173\_v114\_revJ\_10Nov2022  
Last update: 29/02/2024

Flow Cell Number: .....

DNA Samples: .....

INSTRUCTIONS	NOTES/OBSERVATIONS
<ul style="list-style-type: none"> <li><input type="checkbox"/> Thoroughly mix the reaction by gently pipetting and briefly spinning down.</li> <li><input type="checkbox"/> Using a thermal cycler, incubate at 20°C for 5 minutes and 65°C for 5 minutes.</li> <li><input type="checkbox"/> Resuspend the AMPure XP Beads (AXP) by vortexing.</li> <li><input type="checkbox"/> Transfer the DNA sample to a clean 1.5 ml Eppendorf DNA LoBind tube.</li> <li><input type="checkbox"/> Add 60 µl of resuspended the AMPure XP Beads (AXP) to the end-prep reaction and mix by flicking the tube.</li> <li><input type="checkbox"/> Incubate on a Hula mixer (rotator mixer) for 5 minutes at RT.</li> <li><input type="checkbox"/> Prepare 500 µl of fresh 70% ethanol in Nuclease-free water.</li> <li><input type="checkbox"/> Spin down the sample and pellet on a magnet for 10 minutes until the supernatant is clear and colourless. Keep the tube on the magnet, and pipette off the supernatant.</li> <li><input type="checkbox"/> Keep the tube on the magnet and wash the beads with 200 µl of freshly prepared 70% ethanol without disturbing the pellet. Remove the ethanol using a pipette and discard.</li> <li><input type="checkbox"/> Repeat the previous step.</li> <li><input type="checkbox"/> Spin down and place the tube back on the magnet. Pipette off any residual ethanol. Allow to dry for ~30 seconds, but do not dry the pellet to the point of cracking.</li> <li><input type="checkbox"/> Remove the tube from the magnetic rack and resuspend the pellet in 61 µl Nuclease-free water. Incubate for 2 minutes at RT.</li> <li><input type="checkbox"/> Pellet the beads on a magnet until the eluate is clear and colourless, for at least 1 minute.</li> <li><input type="checkbox"/> Remove and retain 61 µl of eluate into a clean 1.5 ml Eppendorf DNA LoBind tube.</li> </ul>	
<p>Quantify 1 µl of eluted sample using a Qubit fluorometer.</p>	
<p>Take forward the repaired and end-prepped DNA into the adapter ligation step. However, at this point it is also possible to store the sample at 4°C overnight.</p>	
<p><b>Adapter ligation and clean-up</b></p>	
<p><b>IMPORTANT</b></p> <p><input type="checkbox"/> Although the recommended third-party ligase is supplied with its own buffer, the ligation efficiency of the Ligation Adapter (LA) is higher when using the Ligation Buffer (LNB) supplied in the Ligation Sequencing Kit.</p>	
<ul style="list-style-type: none"> <li><input type="checkbox"/> Spin down the Ligation Adapter (LA) and Quick T4 Ligase, and place on ice.</li> <li><input type="checkbox"/> Thaw Ligation Buffer (LNB) at RT, spin down and mix by pipetting. Due to viscosity, vortexing this buffer is ineffective. Place on ice immediately after thawing and mixing.</li> <li><input type="checkbox"/> Thaw the Elution Buffer (EB) at RT and mix by vortexing. Then spin down and place on ice.</li> </ul>	

Ligation sequencing gDNA V14 - human sample (N50 10 kb)  
on PromethION (SQK-LSK114)

Version: GDH\_9173\_v114\_revJ\_10Nov2022  
Last update: 29/02/2024

Flow Cell Number: .....

DNA Samples: .....

INSTRUCTIONS	NOTES/OBSERVATIONS
<p><input type="checkbox"/> Thaw the Long Fragment Buffer (LFB) at RT and mix by vortexing. Then spin down and place on ice.</p> <p>In a 1.5 ml Eppendorf DNA LoBind tube, mix in the following order:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> 60 µl DNA sample from the previous step</li> <li><input type="checkbox"/> 25 µl Ligation Buffer (LNB)</li> <li><input type="checkbox"/> 10 µl NEBNext Quick T4 DNA Ligase</li> <li><input type="checkbox"/> 5 µl Ligation Adapter (LA)</li> </ul> <p><input type="checkbox"/> Thoroughly mix the reaction by gently pipetting and briefly spinning down.</p> <p><input type="checkbox"/> Incubate the reaction for 10 minutes at RT.</p> <p><input type="checkbox"/> Resuspend the AMPure XP Beads (AXP) by vortexing.</p> <p><input type="checkbox"/> Add 40 µl of resuspended AMPure XP Beads (AXP) to the reaction and mix by flicking the tube.</p> <p><input type="checkbox"/> Incubate on a Hula mixer (rotator mixer) for 5 minutes at RT.</p> <p><input type="checkbox"/> Spin down the sample and pellet on a magnet. Keep the tube on the magnet, and pipette off the supernatant when clear and colourless.</p> <p><input type="checkbox"/> Wash the beads by adding 250 µl Long Fragment Buffer (LFB). Flick the beads to resuspend, spin down, then return the tube to the magnetic rack and allow the beads to pellet for at least 5 minutes. Remove the supernatant using a pipette and discard.</p> <p><input type="checkbox"/> Repeat the previous step.</p> <p><input type="checkbox"/> Spin down and place the tube back on the magnet. Pipette off any residual supernatant. Allow to dry for ~30 seconds, but do not dry the pellet to the point of cracking.</p> <p><input type="checkbox"/> Remove the tube from the magnetic rack and resuspend the pellet in 25 µl Elution Buffer (EB). Spin down and incubate for 10 minutes at 37°C.</p> <p><input type="checkbox"/> Pellet the beads on a magnet for 10 minutes until the eluate is clear and colourless.</p> <p><input type="checkbox"/> Remove and retain 25 µl of eluate containing the DNA library into a clean 1.5 ml Eppendorf DNA LoBind tube.</p>	
<p>Quantify 1 µl of eluted sample using a Qubit fluorometer.</p>	
<p><input type="checkbox"/> Make up your library to 200-300 ng (30-50 fmol) in 32 µl using Elution Buffer (EB).</p>	
<p><b>IMPORTANT</b></p> <p><input type="checkbox"/> For libraries with an N50 of 10 kb, we recommend loading 200-300 ng (30-50 fmol) of your final prepared library onto the R10.4.1 flow cell.</p>	
<p>The prepared library is used for loading into the flow cell. Store the library on ice or at 4°C until ready to load.</p>	

Ligation sequencing gDNA V14 - human sample (N50 10 kb)  
on PromethION (SQK-LSK114)

Version: GDH\_9173\_v114\_revJ\_10Nov2022  
Last update: 29/02/2024

Flow Cell Number: .....

DNA Samples: .....

INSTRUCTIONS	NOTES/OBSERVATIONS
<p><b>Priming and loading the PromethION Flow Cell</b></p>	
<p><b>IMPORTANT</b></p> <p><input type="checkbox"/> This kit is only compatible with R10.4.1 flow cells (FLO-PRO114M).</p>	
<p><input type="checkbox"/> Thaw the Sequencing Buffer (SB), Library Beads (LIB) or Library Solution (LIS, if using), Flow Cell Tether (FCT) and Flow Cell Flush (FCF) at RT before mixing by vortexing. Then spin down and store on ice.</p> <p>To prepare the flow cell priming mix, combine Flow Cell Tether (FCT) and Flow Cell Flush (FCF), as directed below. Mix by vortexing at RT.</p> <p><input type="checkbox"/> 1,170 µl Flow Cell Flush (FCF)</p> <p><input type="checkbox"/> 30 µl Flow Cell Tether (FCT)</p>	
<p><b>IMPORTANT</b></p> <p><input type="checkbox"/> After taking flow cells out of the fridge, wait 20 minutes before inserting the flow cell into the PromethION for the flow cell to come to RT. Condensation can form on the flow cell in humid environments. Inspect the gold connector pins on the top and underside of the flow cell for condensation and wipe off with a lint-free wipe if any is observed. Ensure the heat pad (black pad) is present on the underside of the flow cell.</p>	
<p>For PromethION 2 Solo, load the flow cell(s) as follows:</p> <p><input type="checkbox"/> Place the flow cell flat on the metal plate.</p> <p><input type="checkbox"/> Slide the flow cell into the docking port until the gold pins or green board cannot be seen.</p> <p>For the PromethION 24/48, load the flow cell(s) into the docking ports:</p> <p><input type="checkbox"/> Line up the flow cell with the connector horizontally and vertically before smoothly inserting into position.</p> <p><input type="checkbox"/> Press down firmly onto the flow cell and ensure the latch engages and clicks into place.</p>	
<p><b>IMPORTANT</b></p> <p><input type="checkbox"/> Insertion of the flow cells at the wrong angle can cause damage to the pins on the PromethION and affect your sequencing results. If you find the pins on a PromethION position are damaged, please contact support@nanoporetech.com for assistance.</p>	
<p><input type="checkbox"/> Slide the inlet port cover clockwise to open.</p>	
<p><b>IMPORTANT</b></p> <p><input type="checkbox"/> Take care when drawing back buffer from the flow cell. Do not remove more than 20-30 µl, and make sure that the array of pores are covered by buffer at all times. Introducing air bubbles into the array can irreversibly damage pores.</p>	
<p>After opening the inlet port, draw back a small volume to remove any air bubbles:</p> <p><input type="checkbox"/> Set a P1000 pipette tip to 200 µl.</p> <p><input type="checkbox"/> Insert the tip into the inlet port.</p> <p><input type="checkbox"/> Turn the wheel until the dial shows 220-230 µl, or until you see a small volume of buffer entering the pipette tip.</p> <p><input type="checkbox"/> Load 500 µl of the priming mix into the flow cell via the inlet port, avoiding the introduction of air bubbles. Wait five minutes. During this time, prepare the library for loading using the next steps in the protocol.</p> <p><input type="checkbox"/> Thoroughly mix the contents of the Library Beads (LIB) by pipetting.</p>	

Ligation sequencing gDNA V14 - human sample (N50 10 kb)  
on PromethION (SQK-LSK114)

Version: GDH\_9173\_v114\_revJ\_10Nov2022  
Last update: 29/02/2024

Flow Cell Number: .....

DNA Samples: .....

INSTRUCTIONS	NOTES/OBSERVATIONS
<p><b>IMPORTANT</b></p> <p><input type="checkbox"/> The Library Beads (LIB) tube contains a suspension of beads. These beads settle very quickly. It is vital that they are mixed immediately before use.</p>	
<p>In a new 1.5 ml Eppendorf DNA LoBind tube, prepare the library for loading as follows:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> 100 µl Sequencing Buffer (SB)</li> <li><input type="checkbox"/> 68 µl Library Beads (LIB) thoroughly mixed before use, or Library Solution (LIS)</li> <li><input type="checkbox"/> 32 µl DNA library</li> </ul> <p><input type="checkbox"/> Complete the flow cell priming by slowly loading 500 µl of the priming mix into the inlet port.</p> <p><input type="checkbox"/> Mix the prepared library gently by pipetting up and down just prior to loading.</p> <p><input type="checkbox"/> Load 200 µl of library into the inlet port using a P1000 pipette.</p> <p><input type="checkbox"/> Close the valve to seal the inlet port.</p>	
<p><b>IMPORTANT</b></p> <p><input type="checkbox"/> Install the light shield on your flow cell as soon as library has been loaded for optimal sequencing output.</p> <p>If the light shield has been removed from the flow cell, install the light shield as follows:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Align the inlet port cut out of the light shield with the inlet port cover on the flow cell. The leading edge of the light shield should sit above the flow cell ID.</li> <li><input type="checkbox"/> Firmly press the light shield around the inlet port cover. The inlet port clip will click into place underneath the inlet port cover.</li> </ul>	
<p>Close the PromethION lid when ready to start a sequencing run on MinKNOW.</p>	
<p><b>Flow cell reuse and returns</b></p>	
<ul style="list-style-type: none"> <li><input type="checkbox"/> After your sequencing experiment is complete, if you would like to reuse the flow cell, please follow the Flow Cell Wash Kit protocol and store the washed flow cell at 2-8°C.</li> <li><input type="checkbox"/> Alternatively, follow the returns procedure to flush out the flow cell ready to send back to Oxford Nanopore.</li> </ul>	
<p><b>IMPORTANT</b></p> <p><input type="checkbox"/> If you encounter issues or have questions about your sequencing experiment, please refer to the Troubleshooting Guide that can be found in the online version of this protocol.</p>	