

Rapid sequencing V14 - Plasmid sequencing (SQK-RBK114.24 or SQK-RBK114.96)

Version: PRB\_9188\_v114\_revE\_17May2023  
 Last update: 25/06/2024

Flow Cell Number: .....

DNA Samples: .....

<b>Before start checklist</b>		
<b>Materials</b>	<b>Consumables</b>	<b>Equipment</b>
<input type="checkbox"/> 50 ng high molecular weight plasmid DNA per sample	<input type="checkbox"/> 1.5 ml Eppendorf DNA LoBind tubes	<input type="checkbox"/> MinION or GridION device
<input type="checkbox"/> Rapid Barcoding Kit 24 V14 (SQK-RBK114.24) OR Rapid Barcoding Kit 96 V14 (SQK-RBK114.96)	<input type="checkbox"/> 2 ml Eppendorf DNA LoBind tubes	<input type="checkbox"/> Ice bucket with ice
	<input type="checkbox"/> 0.2 ml thin-walled PCR tubes or 0.2 ml 96-well PCR plate	<input type="checkbox"/> Microplate centrifuge, e.g. Fisherbrand™ Mini Plate Spinner Centrifuge (Fisher Scientific, 11766427)
	<input type="checkbox"/> Nuclease-free water (e.g. ThermoFisher, AM9937)	<input type="checkbox"/> Timer
	<input type="checkbox"/> Freshly prepared 80% ethanol in nuclease-free water	<input type="checkbox"/> Thermal cycler or heat blocks
	<input type="checkbox"/> Bovine Serum Albumin (BSA) (50 mg/ml) (e.g. Invitrogen™ UltraPure™ BSA 50 mg/ml, AM2616)	<input type="checkbox"/> Magnetic rack
	<input type="checkbox"/> Qubit™ Assay Tubes (Invitrogen, Q32856)	<input type="checkbox"/> Hula mixer (gentle rotator mixer)
	<input type="checkbox"/> Qubit dsDNA HS Assay Kit (Invitrogen, Q32851)	<input type="checkbox"/> Qubit fluorometer (or equivalent for QC check)
		<input type="checkbox"/> Pipettes and pipette tips Multichannel, P2, P20, P100, P200, P1000
INSTRUCTIONS	NOTES/OBSERVATIONS	
<b>Library preparation</b>		
<input type="checkbox"/> Program the thermal cycler: 30°C for 2 minutes, then 80°C for 2 minutes.  Thaw kit components at RT, spin down briefly using a microfuge and mix by pipetting as indicated by the table below:		
<input type="checkbox"/> Rapid Barcodes (RB01-24) or Rapid Barcode Plate (RB01-96): not frozen, briefly spin down, mix well by pipetting		
<input type="checkbox"/> Rapid Adapter (RA): not frozen, briefly spin down, mix well by pipetting		
<input type="checkbox"/> AMPure XP Beads (AXP): thaw at RT, briefly spin down, mix by pipetting or vortexing immediately before use		
<input type="checkbox"/> Elution Buffer (EB): thaw at RT, briefly spin down, mix well by pipetting		
<input type="checkbox"/> Adapter Buffer (ADB): thaw at RT, briefly spin down, mix by vortexing		

Rapid sequencing V14 - Plasmid sequencing (SQK-RBK114.24 or SQK-RBK114.96)

Version: PRB\_9188\_v114\_revE\_17May2023  
 Last update: 25/06/2024

Flow Cell Number: .....

DNA Samples: .....

INSTRUCTIONS	NOTES/OBSERVATIONS
<p>Prepare the DNA in Nuclease-free water, as follows. Approximately 50 ng of plasmid DNA is required in 9 µl of volume for each sample for barcoding.</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> 100 ng/µl 34 µl @ 2 µl (36 µl cycles)</li> <li><input type="checkbox"/> 90 ng/µl 31 µl @ 2 µl (33 µl cycles)</li> <li><input type="checkbox"/> 80 ng/µl 27 µl @ 2 µl (29 µl cycles)</li> <li><input type="checkbox"/> 70 ng/µl 35 µl @ 3 µl (38 µl cycles)</li> <li><input type="checkbox"/> 60 ng/µl 20 µl @ 2 µl (22 µl cycles)</li> <li><input type="checkbox"/> 50 ng/µl 16 µl @ 2 µl (18 µl cycles)</li> <li><input type="checkbox"/> 40 ng/µl 31 µl @ 5 µl (36 µl cycles)</li> <li><input type="checkbox"/> 30 ng/µl 22 µl @ 5 µl (27 µl cycles)</li> <li><input type="checkbox"/> 20 ng/µl 13 µl @ 5 µl (18 µl cycles)</li> <li><input type="checkbox"/> 10 ng/µl 8 µl @ 10 µl (18 µl cycles)</li> <li><input type="checkbox"/> &lt;5.56 ng/µl 0 µl @ 9 µl (9 µl cycles)</li> </ul> <p><input type="checkbox"/> Select a unique barcode for every sample to be run together on the same flow cell. Up to 96 samples can be barcoded and combined in one experiment.</p> <p>In 0.2 ml thin-walled PCR tubes or plate, mix the following reagents. The Rapid Barcodes can be transferred using a multichannel pipette:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> 9 µl 50 ng template DNA</li> <li><input type="checkbox"/> 1 µl Rapid Barcodes (RB01-96, one for each sample)</li> </ul> <p><input type="checkbox"/> Ensure the components are thoroughly mixed by pipetting and spin down briefly.</p> <p><input type="checkbox"/> Incubate the tubes or plate at 30°C for 2 minutes and then at 80°C for 2 minutes. Briefly put the tubes or plate on ice to cool.</p> <p><input type="checkbox"/> Spin down the tubes or plate to collect the liquid at the bottom.</p> <p><input type="checkbox"/> Pool all the barcoded samples into a clean 1.5 ml Eppendorf DNA LoBind tube, noting the total volume.</p> <p><input type="checkbox"/> Resuspend the AMPure XP beads (AXP) by vortexing.</p> <p>To the entire pooled barcoded sample, add an equal volume of resuspended AMPure XP Beads (AXP) and mix by flicking the tube.</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Volume of AXP                     <ul style="list-style-type: none"> <li>- Volume per sample: 10 µl</li> <li>- For 12 samples: 120 µl</li> <li>- For 24 samples: 240 µl</li> <li>- For 48 samples: 480 µl</li> <li>- For 96 samples: 960 µl</li> </ul> </li> </ul> <p><input type="checkbox"/> Incubate on a Hula mixer (rotator mixer) for 5 minutes at RT.</p> <p><input type="checkbox"/> Prepare at least 3 ml of fresh 80% ethanol in Nuclease-free water.</p> <p><input type="checkbox"/> Spin down the sample and pellet on a magnet. Keep the tube on the magnet, and pipette off the supernatant.</p> <p><input type="checkbox"/> Keep the tube on the magnet and wash the beads with 1.5 ml of freshly prepared 80% ethanol without disturbing the pellet. Remove the ethanol using a pipette and discard.</p>	

Rapid sequencing V14 - Plasmid sequencing (SQK-RBK114.24 or SQK-RBK114.96)

Version: PRB\_9188\_v114\_revE\_17May2023  
 Last update: 25/06/2024

Flow Cell Number: .....

DNA Samples: .....

INSTRUCTIONS	NOTES/OBSERVATIONS
<p><input type="checkbox"/> Repeat the previous step.</p> <p><input type="checkbox"/> Briefly spin down and place the tube back on the magnet. Pipette off any residual ethanol. Allow to dry for 30 seconds, but do not dry the pellet to the point of cracking.</p> <p><input type="checkbox"/> Remove the tube from the magnetic rack and resuspend the pellet in 15 µl Elution Buffer (EB). Incubate for 10 minutes at RT.</p> <p><input type="checkbox"/> Pellet the beads on a magnet until the eluate is clear and colourless, for at least 1 minute.</p> <p>Remove and retain 15 µl of eluate into a clean 1.5 ml Eppendorf DNA LoBind tube.</p> <p><input type="checkbox"/> Remove and retain the eluate which contains the DNA library in a clean 1.5 ml Eppendorf DNA LoBind tube</p> <p><input type="checkbox"/> Dispose of the pelleted beads</p>	
<p>Quantify 1 µl of eluted sample using a Qubit fluorometer.</p>	
<p><input type="checkbox"/> Transfer 11 µl of the sample into a clean 1.5 ml Eppendorf DNA LoBind tube.</p> <p>In a fresh 1.5 ml Eppendorf DNA LoBind tube, dilute the Rapid Adapter (RA) as follows and pipette mix:</p> <p><input type="checkbox"/> 1.5 µl Rapid Adapter (RA)</p> <p><input type="checkbox"/> 3.5 µl Adapter Buffer (ADB)</p> <p><input type="checkbox"/> Add 1 µl of the diluted Rapid Adapter (RA) to the barcoded DNA.</p> <p><input type="checkbox"/> Mix gently by flicking the tube, and spin down.</p> <p><input type="checkbox"/> Incubate the reaction for 5 minutes at RT.</p>	
<p>The prepared library is used for loading into the flow cell. Store the library on ice until ready to load.</p>	
<p><b>Priming and loading the SpotON flow cell</b></p>	
<p><b>IMPORTANT</b></p> <p><input type="checkbox"/> Please note, this kit is only compatible with R10.4.1 flow cells (FLO-MIN114).</p>	
<p><input type="checkbox"/> Thaw the Sequencing Buffer (SB), Library Beads (LIB) or Library Solution (LIS, if using), Flow Cell Tether (FCT) and Flow Cell Flush (FCF) at RT before mixing by vortexing. Then spin down and store on ice.</p>	
<p><b>IMPORTANT</b></p> <p><input type="checkbox"/> For optimal sequencing performance and improved output on MinION R10.4.1 flow cells (FLO-MIN114), we recommend adding Bovine Serum Albumin (BSA) to the flow cell priming mix at a final concentration of 0.2 mg/ml.</p>	
<p>To prepare the flow cell priming mix with BSA, combine the following reagents and pipette mix at RT:</p> <p><input type="checkbox"/> 1,170 µl Flow Cell Flush (FCF)</p> <p><input type="checkbox"/> 5 µl Bovine Serum Albumin (BSA) at 50 mg/ml</p> <p><input type="checkbox"/> 30 µl Flow Cell Tether (FCT)</p> <p><input type="checkbox"/> Open the MinION or GridION device lid and slide the flow cell under the clip. Press down firmly on the flow cell to ensure correct thermal and electrical contact.</p>	

Rapid sequencing V14 - Plasmid sequencing (SQK-RBK114.24 or SQK-RBK114.96)

Version: PRB\_9188\_v114\_revE\_17May2023  
 Last update: 25/06/2024

Flow Cell Number: .....

DNA Samples: .....

INSTRUCTIONS	NOTES/OBSERVATIONS
<input type="checkbox"/> Slide the flow cell priming port cover clockwise to open the priming port.	
<p><b>IMPORTANT</b></p> <input type="checkbox"/> Take care when drawing back buffer from the flow cell. Do not remove more than 20-30 $\mu$ l, and make sure that the array of pores are covered by buffer at all times. Introducing air bubbles into the array can irreversibly damage pores.	
<p>After opening the priming port, check for a small air bubble under the cover. Draw back a small volume to remove any bubbles:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Set a P1000 pipette to 200 <math>\mu</math>l</li> <li><input type="checkbox"/> Insert the tip into the priming port</li> <li><input type="checkbox"/> Turn the wheel until the dial shows 220-230 <math>\mu</math>l, to draw back 20-30 <math>\mu</math>l, or until you can see a small volume of buffer entering the pipette tip</li> </ul> <p>Note: Visually check that there is continuous buffer from the priming port across the sensor array.</p> <input type="checkbox"/> Load 800 $\mu$ l of the priming mix into the flow cell via the priming port, avoiding the introduction of air bubbles. Wait for five minutes. During this time, prepare the library for loading by following the steps below. <input type="checkbox"/> Thoroughly mix the contents of the Library Beads (LIB) by pipetting.	
<p><b>IMPORTANT</b></p> <input type="checkbox"/> The Library Beads (LIB) tube contains a suspension of beads. These beads settle very quickly. It is vital that they are mixed immediately before use.	
<p>In a new 1.5 ml Eppendorf DNA LoBind tube, prepare the library for loading as follows:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> 37.5 <math>\mu</math>l Sequencing Buffer (SB)</li> <li><input type="checkbox"/> 25.5 <math>\mu</math>l Library Beads (LIB) mixed immediately before use, or Library Solution (LIS), if using</li> <li><input type="checkbox"/> 12 <math>\mu</math>l DNA library</li> </ul> <p>Complete the flow cell priming:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Gently lift the SpotON sample port cover to make the SpotON sample port accessible.</li> <li><input type="checkbox"/> Load 200 <math>\mu</math>l of the priming mix into the flow cell priming port (not the SpotON sample port), avoiding the introduction of air bubbles.</li> <li><input type="checkbox"/> Mix the prepared library gently by pipetting up and down just prior to loading.</li> <li><input type="checkbox"/> Add 75 <math>\mu</math>l of the prepared library to the flow cell via the SpotON sample port in a dropwise fashion. Ensure each drop flows into the port before adding the next.</li> <li><input type="checkbox"/> Gently replace the SpotON sample port cover, making sure the bung enters the SpotON port and close the priming port.</li> </ul>	
<p><b>IMPORTANT</b></p> <input type="checkbox"/> Install the light shield on your flow cell as soon as library has been loaded for optimal sequencing output.	
<p>Place the light shield onto the flow cell, as follows:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Carefully place the leading edge of the light shield against the clip. Note: Do not force the light shield underneath the clip.</li> <li><input type="checkbox"/> Gently lower the light shield onto the flow cell. The light shield should sit around the SpotON cover, covering the entire top section of the flow cell.</li> </ul>	

Rapid sequencing V14 - Plasmid sequencing (SQK-RBK114.24 or SQK-RBK114.96)



Version: PRB\_9188\_v114\_revE\_17May2023  
 Last update: 25/06/2024

Flow Cell Number: .....

DNA Samples: .....

INSTRUCTIONS	NOTES/OBSERVATIONS
Close the device lid and set up a sequencing run on MinKNOW.	
<b>Ending the experiment</b>	
<input type="checkbox"/> After your sequencing experiment is complete, if you would like to reuse the flow cell, please follow the Flow Cell Wash Kit protocol and store the washed flow cell at 2-8°C.  <input type="checkbox"/> Alternatively, follow the returns procedure to flush out the flow cell ready to send back to Oxford Nanopore.	
<b>IMPORTANT</b>  <input type="checkbox"/> If you encounter issues or have questions about your sequencing experiment, please refer to the Troubleshooting Guide that can be found in the online version of this protocol.	